


**BEFORE STARTING, PLEASE READ AND FOLLOW ALL SAFETY INSTRUCTIONS FROM THE MANUFACTURERS OF MINI-LIGHTS YOU USE.**

1. When installing or removing lights from letter panels, **MAKE SURE LIGHTS ARE UNPLUGGED FROM THE POWER SOURCE!**
2. Keep away from children, this is not a toy.
3. When working with the mini light strand, always hold the strand by the socket. **DON'T PULL ON THE WIRES BECAUSE YOU MAY DAMAGE THE LIGHT SET!**
4. Do not hang panels from light string, cords or wires.
5. **DO NOT USE FOR ANYTHING OTHER THAN INTENDED USE.**

**THINGS TO KNOW BEFORE GETTING STARTED**

Re-usable Snap-N-Glow™ panels work with most brands of light. There are two to three oversized mini light sockets that will not fit into the holes of the letter panel. Just Black-Out those lights with Black-Out Caps™ and move onto the next bulb socket on the mini light strand. There is a "FRONT" and "BACK" to each Snap-N-Glow™ panel. There are 35 holes on each panel numbers 1-35. 100-mini lights will fill 4 to 5 Snap-N-Glow™ panels.


Stakes/Gutter Clips



**DIRECTIONS: STAKE & GUTTER CLIP**

- TO USE AS A STAKE:** Snap stake into bottom square holes on the left and right corners of the "BACKSIDE" side of panel.
2. **STAKES ARE MEANT FOR SOFT SURFACES ONLY! DO NOT INSERT INTO HARD SURFACE.**
  3. **TO USE AS A GUTTER CLIP:** Snap Clip/Stake into top square holes on the left and right corners of the "BACKSIDE" of panel.

Letter Panels



**DIRECTIONS: INSTALLATION OF MINI LIGHTS INTO PANELS**

- Snap panels together to form words – one panel per letter or number.
2. Slide the light bulb socket completely through the "BACKSIDE" of the letter panel through desired numbered hole on panel. (SEE LETTER INSTRUCTIONS, on back)
  3. Push wires down so they rest inside the horseshoe portion of the hole.
  4. Slide mini light socket back through the horseshoe portion of the hole and press firmly into place at bottom of each hole.
  5. Repeat motion to form letters or numbers.

**DIRECTIONS: INSTALLATION AND USE OF CAPS**

- Installation is simple: Just slide the Black-Out Cap™ over the unwanted light bulb.
2. The Black-Out Caps™ give you the look of a professionally installed lighting display by covering individual bulbs on unwanted sections of a light strand.
  3. Use Black-Out Caps™ to cover unwanted mini lights between words panels, or any extra mini lights left over.

**BLACK-OUT CAPS CAUTION**

Intended for outside use.  
Keep away from children. May be choking hazard.  
PRODUCT MAY GET HOT. Turn mini lights off and allow time to cool before touching or removing.  
Product is intended for temporary display only – not for permanent installation.

Black-Out Caps




Figure 3.


**DIRECTIONS: INSTALLATION OF MINI LIGHTS INTO PANEL:** Before locking lights into place be sure to Snap panels together to form custom word desired – one panel per letter or number.

**Step 1** Slide the light bulb socket completely through the “BACKSIDE” hole of the letter panel through desired numbered hole on panel


**Step 2** Push wires down so they rest inside the horseshoe portion of the hole.

**Step 3** Slide mini light socket back through the horseshoe portion of the hole and press firmly into place at bottom of each hole.


**WARNING! DO NOT ATTEMPT TO SNAP MINI LIGHTS INTO PLACE! MUST SLIDE SOCKET INTO HORSESHOE.**



Push light Socket completely through upper Portion of hole.



Once light socket is completely through, push wire down into horseshoe Portion.



Slide socket back into horseshoe portion until it locks. **DO NOT PULL ON WIRE!**

**HOW TO MAKE: Letters**

- A - Start at 31, 26, 21, 16, 11, 6, 1, 2, 3, 4, 5, 10, 15, 20, 25, 30, 35, 17, 18, 19
- B - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 30, 25, 19, 18, 17, 2, 3, 4, 10, 15
- C - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 35, 2, 3, 4, 5
- D - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 29, 25, 20, 15, 9, 3, 2
- E - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 35, 19, 18, 17, 2, 3, 4, 5
- F - Start at 1, 6, 11, 16, 21, 26, 31, 19, 18, 17, 2, 3, 4, 5
- G - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 35, 30, 25, 20, 19, 18, 2, 3, 4, 5
- H - Start at 1, 6, 11, 16, 21, 26, 31, 35, 30, 25, 20, 19, 18, 17, 15, 10, 5
- I - Start at 1, 31, 32, 33, 34, 35, 28, 23, 18, 13, 8, 2, 3, 4, 5
- J - Start at 21, 26, 32, 33, 34, 30, 25, 20, 15, 10, 5
- K - Start at 1, 6, 11, 16, 21, 26, 31, 35, 29, 24, 18, 17, 14, 9, 5
- L - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 35
- M - Start at 31, 26, 21, 16, 11, 6, 1, 7, 12, 18, 14, 9, 5, 10, 15, 20, 25, 30, 35
- N - Start at 31, 26, 21, 16, 11, 6, 1, 7, 12, 18, 24, 29, 35, 30, 25, 20, 15, 10, 5
- O - Start at 6, 11, 16, 21, 26, 32, 33, 34, 30, 25, 20, 15, 10, 4, 3, 2
- P - Start at 31, 26, 21, 16, 11, 6, 1, 2, 3, 4, 5, 10, 15, 19, 18, 17
- Q - Start at 6, 11, 16, 21, 26, 32, 33, 34, 35, 29, 25, 20, 15, 10, 4, 3, 2
- R - Start at 1, 6, 11, 16, 21, 26, 31, 35, 29, 24, 17, 18, 19, 15, 10, 4, 3, 2
- S - Start at 26, 32, 33, 34, 30, 25, 19, 18, 17, 11, 6, 2, 3, 4, 10
- T - Start at 1, 33, 28, 23, 18, 13, 8, 2, 3, 4, 5
- U - Start at 1, 6, 11, 16, 21, 26, 32, 33, 34, 30, 25, 20, 15, 10, 5
- V - Start at 1, 6, 11, 16, 21, 27, 33, 29, 25, 20, 15, 10, 5
- W - Start at 1, 6, 11, 16, 21, 26, 31, 27, 22, 18, 24, 29, 35, 30, 25, 20, 15, 10, 5
- X - Start at 1, 7, 12, 18, 24, 29, 35, 31, 27, 22, 14, 9, 5
- Y - Start at 1, 7, 12, 23, 28, 33, 18, 14, 9, 5
- Z - Start at 1, 2, 3, 4, 5, 9, 14, 18, 22, 27, 31, 32, 33, 34, 35

**HOW TO MAKE: Numbers**

- 1 - Start at 7, 3, 8, 13, 18, 23, 28, 31, 32, 33, 34, 35
- 2 - Start at 1, 2, 3, 4, 5, 10, 15, 20, 19, 18, 17, 16, 21, 26, 31, 32, 33, 34, 35
- 3 - Start at 1, 2, 3, 4, 5, 10, 15, 25, 30, 35, 34, 33, 32, 31, 17, 18, 19, 20
- 4 - Start at 1, 6, 11, 16, 17, 18, 19, 35, 30, 25, 20, 15, 10, 5
- 5 - Start at 1, 6, 11, 16, 26, 32, 33, 34, 30, 25, 20, 19, 18, 17, 2, 3, 4, 5
- 6 - Start at 1, 6, 11, 16, 21, 26, 31, 32, 33, 34, 35, 30, 25, 20, 19, 18, 17, 2, 3, 4, 5
- 7 - Start at 1, 2, 3, 4, 5, 9, 14, 18, 22, 27, 31
- 8 - Start at 2, 6, 11, 21, 26, 32, 33, 34, 30, 25, 19, 18, 17, 15, 10, 4, 3
- 9 - Start at 1, 6, 11, 16, 31, 32, 33, 34, 35, 30, 25, 20, 19, 18, 17, 2, 3, 4, 5, 10, 15



Look for other Great Products from **St. Nick's Choice:**

- ***Wrap-N-Roll*** T.M.
- ***Black-Out Caps*** T.M.
- ***Reach-N-Wrap*** T.M.